

## Universal wall mount for chargers (pedelec/e-bike)



### Installation:

If no fixing materials were ordered:

The two slotted holes on the back plate are designed for 6 mm diameter screws.

Fixing materials ordered for timber beams, stone and concrete walls consisting of:

2x Fischer DuoPower two-component wall plugs 8x40 mm

2x flat-head wood screws 6.3x50mm

Wood: we recommend pre-drilling using a 4–5mm wood drill bit

Stone and concrete walls: Ø8mm drill bit, drill hole depth 50mm – (remove drill dust)

Tools required: 4mm Allen key

When choosing the installation location, ensure the charging cable can reach the bike's charging socket.

### Operation:

Stretch the BicycleJack Velcro strap, guide the charger in from above, ensuring the cable is fed neatly through the lower opening of the mount.

Then pull the Velcro strap tight to secure the charger. When not in use, the charger plugs can be stored in the slots on the left and right.

When charging the bike on the BicycleJack, place the supplied Velcro strap marked "Remove charger plug" over the tip of the saddle – this is to remind you that the charging plug is still connected before removing the bike from the mount. Otherwise, this may result in significant/costly damage to the plug or the bike's charging socket.

When not in use, reattach the Velcro strap to the front mounting tab of the wall bracket.



**We hope you enjoy this product for a long time to come**