

B:CYCLE JACK

Safety instructions

Please note: Before using the Bicyclejack for the first time, please read the following safety instructions carefully and ensure that every operator is made aware of them!

! Do not hold your head or any other part of your body over the lever arm as it moves upwards!

! The BicycleJack is designed exclusively for bicycles with the weight specified on the BicycleJack. It must only be operated by trained personnel – do not allow children to play with it!

! Ensure that the handlebar ends or other protruding parts of the bicycle cannot become caught in your clothing during the lifting process!

User Manual

Parking your bike

The bike can be parked at any angle to the mounting surface (*"BicycleJack Basic" version: only at a right angle to the mounting surface*)

The lever arm must be in the lowered position (for first-time use: see step 6 of the installation instructions). Important: ensure that the lever arm is secured against accidental raising by the existing lift lock!

Lift the front wheel of the bicycle and hook it into the mounting bracket in the area without a bicycle valve. Release the lock with your left hand by pulling the black ball knob towards you (*"BicycleJack Basic" version: simply pull out the locking button and turn it so that the lever arm is released*). Use your right hand to balance the bicycle. Then, using your left hand, lift the lever arm together with the front wheel by approx. 5 cm (keeping your body out of the way of the lifting movement). The BicycleJack will now automatically continue the lifting process and raise the bicycle to a vertical position. The bicycle is guided until the end position is reached. When using the optional 'MagFix' magnetic fixing (Twist version only) and a weaker gas spring, you may need to manually assist the bike as it moves into the parking position until 'MagFix' audibly engages with a 'click'. Both wheels should finally rest in the wheel recesses (optional). To prevent theft, the bicycle can be secured with a bicycle lock attached to the steel eyelet at the bottom of the BicycleJack (*"BicycleJack Basic" version: oval opening in the central frame*).

The bike, together with the BicycleJack, can then be swivelled sideways in both directions (*not available in the 'BicycleJack Basic' version*).

Unlock the bike

The bike can be removed from the parking space at any angle to the mounting surface werden (*"BicycleJack Basic" version: only at a right angle to the mounting surface*)

First, remove the bike lock.

B:CYCLE JACK

Stand a **short distance (approx. 0.5 m)** behind the parked bicycle. Reach under the saddle with your right hand and guide the bicycle backwards into the space (if the 'MagFix' magnetic fixing is fitted, the magnetic connection will release) until you feel the resistance of the gas spring. Only now should you pull the bicycle backwards into the free space with the appropriate momentum and a light touch, guiding the bicycle by the handlebars with your other hand to support it during the process. This requires a bit of practice, but should go smoothly after 5-10 attempts. Once the lever arm is in the lowest position, the lock engages. (*"BicycleJack Basic" version: engage manually by turning the locking knob in the lever arm!*). You should always check this again! The bike can now be safely removed from the hook.